





## Closure Caps



Closure caps are for unused ports on the junction box.

| Dimensions   | Description  |
|--|--|
| <p style="text-align: center;"><b>RKMV BC</b></p>             | <p><b>minifast®</b> closure cap</p> <ul style="list-style-type: none"> <li>• mates to male receptacles</li> <li>• Stainless steel</li> <li>• IP67 rated</li> </ul>   |
| <p style="text-align: center;"><b>RSMV BC</b></p>            | <p><b>minifast®</b> closure cap</p> <ul style="list-style-type: none"> <li>• mates to female receptacles</li> <li>• Stainless steel</li> <li>• IP67 rated</li> </ul> |
| <p style="text-align: center;"><b>RSFK-BC (10/BAG)</b></p>  | <p><b>minifast®</b> Closure Cap</p> <ul style="list-style-type: none"> <li>• mates to female receptacles</li> <li>• nylon</li> </ul>                                 |
| <p style="text-align: center;"><b>VZ-3 (8/BAG)</b></p>      | <p><b>eurofast®</b> Closure Cap</p> <ul style="list-style-type: none"> <li>• mates to female receptacles</li> <li>• nylon</li> </ul>                                 |